


Whirlpool WED94HEXW2 01 - TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

For Models: WED94HEXW2, WED94HEXR2, WED94HEXL2
(White) (Red) (Lunar Silver)

27" ELECTRIC DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

2-12 Litho in U.S.A. (BMN) (psw)

1

Part No. W10479706 Rev. A

Whirlpool [Residential Whirlpool WED94HEXW2 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10305730		Not Available	USE & CARE GUIDE (ENGLISH)
"	W10420005		Not Available	TECH SHEET
"	W10423118		Not Available	INSTALLATION, INSTRUCTION
2	W10208383			Top
"	W10337792			Top
"	W10316282			Top
3	W10441589			Harness, Main
4	W10464682			Panel, Console
"	W10464684			Panel, Console
"	W10464683			Panel, Console
5	W10317570			Water Channel
6	W10208198			Bracket, Console
7	W10267938			Harness, UI Jumper
8	W10267937			Harness, Jumper
9	W10117943	8303811		Badge, Assembly

10	693995		Screw, Hex Head
11	3390647	488729	Screw
12	W10450060	Not Available	CABLE, USER INTERFACE
13	W10317566		Spring, Clip Water Channel

