


Whirlpool WED9500TW0 02 - CABINET PARTS



W10163412

3

Whirlpool [Residential Whirlpool WED9500TW0 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8576583	W10119283		Cover, Terminal Block
2	3390814	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
3	697776	4331106		Screw, No.10-32 X 7/16
4	3397659			Block, Terminal
5	3394881	279782		Switch-Lid
6	3357011	308685		Side Trim)
7	W10138989	W10117272		Panel
"	W10139000	W10156769		Panel
8	3392100	49621		Feet-Leveling
"	279810			Foot-Optional
9	660658			Clamp, Motor Mounting 343481 685441
10	3387374			Spring, Idler
11	3389420			Retainer-Idler 1/4-20 X 1/16
12	697750	W10470674		Dryer Exhaust Kit
"	W10136988			Plug, Multivent

13	3388672	279640	Pulley-ldr
14	279318		Terminal Tinned And Brass Panel
15	8066120		Lever, Door Switch
16	3394081		Wire, Broken Belt Switch
17	W10128772	8564134	Board, Sound Dampening
18	233520		Washer, Thrust
19	W10128087	W10318609	Switch, Assembly Door
20	W10121334		Washer, Thrust
21	8066115	3394331	Plate Cover
22	8529053		Ramp, Door Door Switch
23	W10118614		Seal, Door Switch
24	W10139003	W10117273	Panel
"	W10139014	W10156775	Panel
25	W10118470		Cover, Bracket Control
26	343641	681414	Screw, 10AB X 1/2
27	8538263	279787	Motor-Drve
28	3398948		Wire, Jumper
29	8578220		Pulley, Motor
30	3387610	661570	Belt
31	W10133213	W10202864	Panel-Rear
32	3387118		Bracket, Motor
33	279393		Terminal Block Screw Kit
34	49026		4" - 90° Elbow
35	W10116271	W10246269	Panel, Toe
"	W10140573		Panel, Toe
36	8563747		Exhaust Pipe Medium Pipe
37	8563750		Exhaust Pipe
38	8563749		Exhaust Pipe
39	3388674	W10118756	Idler Bracket
40	W10141671		Board, Control
41	8563727		Bracket, Control
42	98129		Screw, 6-20 X 1 1/16
43	3390647	488729	Screw
44	3387242		Seal, Front Panel
45	3393008	308685	Side Trim)
46	8519459		Clip, Toe Panel
47	W10110990	W10181463	Harness, Digital Interface
48	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
49	696144	279570	Latch
50	8519207		Base, Cabinet
51	8578388		Front Panel
"	W10140575		Front Panel
52	3407228		Assembly, Power Cube
53	3389682		Space-Toe Panel User-Interface
54	62825		Clip-S Type Control Board
"	BLANK		Not Available
55	279818	W10470674	Dryer Exhaust Kit
"	W10152955	W10470674	Dryer Exhaust Kit