


# Whirlpool WED95HEXW0 01 - TOP AND CONSOLE PARTS



Whirlpool [Residential Whirlpool WED95HEXW0 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10305730		Not Available	USE & CARE GUIDE (ENGLISH)
"	W10306459		Not Available	USE & CARE GUIDE (TECH SHEET INSTALLATION, INSTRUCTION)
"	W10057363		Not Available	USE & CARE GUIDE (ENGLISH)
2	<a href="#">W10208383</a>			Top
"	<a href="#">W10337792</a>			Top
"	<a href="#">W10316282</a>			Top
3	<a href="#">W10267281</a>			Harness, Main
4	<a href="#">W10352457</a>			Panel, Console Assembly
"	<a href="#">W10352461</a>			Panel, Console Assembly
"	<a href="#">W10352459</a>			Panel, Console Assembly
5	<a href="#">W10317570</a>			Water Channel
6	<a href="#">W10208198</a>			Bracket, Console
7	<a href="#">W10267937</a>			Harness, Jumper
8	<a href="#">W10267938</a>			Harness, UI Jumper

9	W10117943	<a href="#">8303811</a>	Badge, Assembly
10	<a href="#">693995</a>		Screw, Hex Head
11	3390647	<a href="#">488729</a>	Screw
12	<a href="#">W10267833</a>		Cable, Led User-Interface
13	<a href="#">W10317566</a>		Spring, Clip Water Channel

