


Whirlpool WED9600SU0 01 - TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

For Model: WED9600SU0
(Ultimate Silver)

ELECTRIC DRYER



2-07 Litho in U.S.A.(LT)

1

Part No. W10117787 Rev. A

Whirlpool Residential Whirlpool WED9600SU0 Dryer Parts Parts Diagram 01 - TOP AND CONSOLE PARTS

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10110850		Not Available	Use & Care Guide
"	W10110638		Not Available	Tech Sheet
"	W10111226		Not Available	Guide, Quick Start
2	W10114785			Top
3	8579739			Harness, Main
4	W10116697			Panel, Console
5	3394427			Clip-Harness
6	W10006840	W10215656		Bracket, Console
7	353424			Plug, Terminal
8	94614			Terminal
9	3936144			Do-It-Yourself Repair Manuals
10	94613	596797		Terminal
11	3390647	488729		Screw
12	W10112267			Foam-Seal Control Bracket
13	W10030070	W10012480		Kit
14	3936150			Connector, 7-Circuit

15	3395683		Receptacle, Multi-Terminal
16	8281225		Screw, 8-18 X 1/2
17	2203186		Connector, 5-Circuit
18	W10031430	W10294629	Kit
19	W10048210	W10121375	User Interface
20	W10012430		Encoder, Wheel Kit.
21	W10012440		Retainer-Snap
22	W10012410		Knob, Light Ring
23	W10012810	280230	Encoder, Wheel Kit.
24	W10012460	280230	Encoder, Wheel Kit.
25	W10112268		Clip-Harness
26	W10012820	280230	Encoder, Wheel Kit.
27	W10116704		Knob, Control
28	280230		Encoder, Wheel Kit.
29	W10095960		Harness, Communication
30	3391018		Tie Cable

