


Whirlpool WED9600TU0 04 - DOOR PARTS, OPTIONAL PARTS (NOT INCLUDED)

DOOR PARTS

For Models: WED9600TW0, WED9600TU0, WED9600TA0, WED9600TZ0, WED9600TB0
(White) (Ultimate Silver) (Aspen) (White/Blue) (Black/Chrome)



W10145263

7

Whirlpool [Residential Whirlpool WED9600TU0 Dryer Parts](#) Parts Diagram 04 - DOOR PARTS, OPTIONAL PARTS (NOT INCLUDED)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10085210			Label-Hinge Hole Cover Front Panel
2	W10139920			Door Hinge Assembly
3	W10017850	280203		Screw-Kit
4	9742177			Screw, 8-18 X .625
5	8578153	W10180119		Cover-Hinge, Stationary Cover Hinge
"	BLANK		Not Available	(Following Parts Not Included)
"	8578152	W10181197		Cover Hinge
6	W10139457			Seal-Door Handle, Ring Door
7	W10048070	8579502		Handle, Door
"	W10048010	8579496		HAndle, Ring And Pad Assembly
8	3393008	308685		Side Trim)
9	8579520	W10180115		Door Assembly
10	8578229			Door Assembly

11	355515		Screw, 8-18 X 11/16
12	3398175	279570	Latch
13	8519356		Retainer-Window
14	8519354		Retainer-Window
15	8579662		Gasket, Window
16	W10048910		Screw-Plug
17	8566254		Glass-Window
18	8580116	W10121607	Pad, Door Handle
19	W10133736	W10180500	Tear-Drop Trim And Clip Assembly
"	W10133739	Not Available	Tear-Drop Trim & Clip Assembly (Ultimate Silver)
"	W10133740	W10180504	Tear-Drop Trim And Clip Assembly
"	W10133741	Not Available	Tear-Drop Trim & Clip Assembly (White/Blue)
"	W10133737	Not Available	Tear-Drop Trim & Clip Assembly (Black/Chrome)
20	W10074630	W10180120	Shield, Door
21	8578157	W10180118	Door, Intermediate
22	8578156		Door Mask
23	8578155		Door Screen
24	3393258	3373329D	Screw
25	W10129065		Trim-Clip Metal
27	690081	279570	Latch
"	72017		Paint, Touch-Up
"	72302	Not Available	PAINT, TOUCH-UP (1/2oz.) (Black)
"	8212605		Paint, Pressurized Spray
"	W10157756		Paint, Touch-Up
"	350930		Paint, Pressurized Spray B
"	786020	Not Available	PAINT, PRESSURIZED SPRAY (12 oz.) (Black)
"	350938		Paint, Pressurized Spray B
"	799344		Paint, Touch-Up)
"	786302	Not Available	PAINT, BULK (1 qt.) (Black (Uncut))
"	BLANK	Not Available	ACCESSORY PARTS
"	8529894	346764	Kit, Hold Down
"	8541503		Kit, Stack Assembly
"	8579666A	W10466829	Blade
"	80047		PAINT, BULK (1 QT.) (KIT, DRYER REPAIR)
"	8521957	W10121663	Dryer Rack
"	BLANK	Not Available	Following Parts Not Illustrated
"	76314		Hose, Inlet 6 Ft. Hose With Elbow
"	W10044603		Connector, Hose ``Y``
"	3976300	16123	Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
"	W10044604	49586	Mixer