


# Whirlpool WED9600TW1 01 - TOP AND CONSOLE PARTS



3-08 Litho in U.S.A.(LT)

1

Part No. W10194217 Rev. A

Whirlpool Residential Whirlpool WED9600TW1 Dryer Parts Parts Diagram 01 - TOP AND CONSOLE PARTS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10136968		Not Available	Use & Care Guide
"	W10177462		Not Available	Tech Sheet
"	W10139791		Not Available	Guide, Quick Start
"	W10134980		Not Available	Installation, Diagonostic Guide
"	W10139322		Not Available	TIP SHEET DRYER STEAM
2	8519251	<a href="#">W10117263</a>		Top
"	<a href="#">W10114785</a>			Top
"	<a href="#">W10140290</a>			Top
"	8579997	<a href="#">W10192490</a>		Top
3	W10111017	<a href="#">W10238916</a>		Harness, Main
4	<a href="#">W10153650</a>			Panel, Console
"	W10153654		Not Available	Panel, Console (Includes Illus: 20,21,22,27,28 & 29) (Ultimate Silver)
"	<a href="#">W10153655</a>			Panel, Console
"	<a href="#">W10153652</a>			Panel, Console
5	<a href="#">3391018</a>			Tie Cable

6	W10006840	<a href="#">W10215656</a>	Bracket, Console
7	<a href="#">W10112268</a>		Clip-Harness
8	<a href="#">94614</a>		Terminal
9	<a href="#">3936144</a>		Do-It-Yourself Repair Manuals
10	94613	<a href="#">596797</a>	Terminal
11	3390647	<a href="#">488729</a>	Screw
12	<a href="#">W10112267</a>		Foam-Seal Control Bracket
13	W10030070	<a href="#">W10012480</a>	Kit
14	<a href="#">3936150</a>		Connector, 7-Circuit
15	<a href="#">3395683</a>		Receptacle, Multi-Terminal
16	98139	<a href="#">303776</a>	Screw
17	<a href="#">2203186</a>		Connector, 5-Circuit
18	W10172217	<a href="#">W10294709</a>	Kit
19	<a href="#">W10110658</a>		User Interface
20	<a href="#">W10012430</a>		Encoder, Wheel Kit.
21	<a href="#">W10012440</a>		Retainer-Snap
22	<a href="#">W10012410</a>		Knob, Light Ring
23	W10012810	<a href="#">280230</a>	Encoder, Wheel Kit.
24	W10012460	<a href="#">280230</a>	Encoder, Wheel Kit.
25	<a href="#">W10095960</a>		Harness, Communication
26	W10012820	<a href="#">280230</a>	Encoder, Wheel Kit.
27	<a href="#">W10116702</a>		Knob, Control
"	<a href="#">W10116704</a>		Knob, Control
"	<a href="#">W10153663</a>		Knob, Control
"	<a href="#">W10116705</a>		Knob, Control
28	<a href="#">280230</a>		Encoder, Wheel Kit.
29	W10117943	<a href="#">8303811</a>	Badge, Assembly
30	<a href="#">W10111020</a>		Power Cable, User-Interface

*the laundry company*<sup>®</sup>

**lws**  
*the laundry company*<sup>®</sup>