


# Whirlpool WED97HEXW2 04 - DOOR PARTS

## DOOR PARTS

For Models: WED97HEXW2, WED97HEXR2, WED97HEXL2  
(White) (Red) (Lunar Silver)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

W10440204

7

Whirlpool [Residential Whirlpool WED97HEXW2 Dryer Parts](#) Parts Diagram 04 - DOOR PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">W10208266</a>			Door, Inner Assembly
2	<a href="#">W10208415</a>			Hinge Base
3	<a href="#">W10208270</a>			Door, Outer Screen
4	<a href="#">9742177</a>			Screw, 8-18 X .625
5	<a href="#">W10208411</a>			Handle, Door
6	<a href="#">W10208413</a>			Cover, Door Switch
7	<a href="#">W10208271</a>			Door, Trim Ring
8	<a href="#">W10208419</a>			Plate, Hinge Retainer
9	<a href="#">W10208268</a>			Door Assembly (Outer) (Include Items, (3, 4, 5, 7 And 14)
10	<a href="#">W10267837</a>			Door, Inner Assembly
11	<a href="#">W10288126</a>			Screw, 10-32 X 1/2
12	<a href="#">W10208254</a>			Door Inner Screw, 10-32 X 1/2
13	<a href="#">W10208252</a>			Bracket, Glass
14	<a href="#">W10208269</a>			Frame, Door Front Support
15	<a href="#">W10329710</a>			Door Catch Assembly

