



**NON – ILLUSTRATED  
PARTS**

Includes

Optional Parts

Parts Not Included

Miscellaneous Parts

Whirlpool Residential Whirlpool WET3300XQ0 Washer/Dryer Parts Parts Diagram 14 - OPTIONAL PARTS (NOT INCLUDED)

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
NI	<a href="#">72017</a>			Paint, Touch-Up
"	<a href="#">4392899</a>			Paint, Touch-Up
"	<a href="#">350938</a>			Paint, Pressurized Spray B
"	<a href="#">350930</a>			Paint, Pressurized Spray B
"	<a href="#">4392901</a>			Paint, Pressurized Spray
"	<a href="#">799344</a>			Paint, Touch-Up )
"	<a href="#">4392900</a>			Paint, Bulk )
"	<a href="#">350572</a>			Oil
"	<a href="#">285208</a>			Lubricant
"	<a href="#">285195</a>			Sealer Sealer, Gasket
"	<a href="#">279823</a>			Side Exhaust Extension Kit