


# Whirlpool WFW8300SW0 03 - CONTROL PANEL PARTS



Whirlpool [Residential Whirlpool WFW8300SW0 Washer Parts](#) Parts Diagram 03 - CONTROL PANEL PARTS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8574927	<a href="#">W10099593</a>		Panel, Control
2	8571944	<a href="#">8574963</a>		Knob, Control
3	<a href="#">8571903</a>			User Interface
4	8540558	<a href="#">W10240776</a>		Brace, Top Front
5	<a href="#">8540839</a>			Channel, Water
6	8541000	<a href="#">W10205839</a>		Control-Elec
7	3390647	<a href="#">488729</a>		Screw
8	8540703	<a href="#">W10169929</a>		Harness, Wiring
9	8540282	<a href="#">8181661</a>		Screw, Actuator
10	W10015090	<a href="#">489442</a>		Screw 3 2217757 Roller, Front