


Whirlpool WFW8300SW04 02 - DOOR AND LATCH PARTS

DOOR AND LATCH PARTS

For Model: WFW8300SW04
(White/Grey)



W10205674

3

Whirlpool [Residential Whirlpool WFW8300SW04 Washer Parts](#) Parts Diagram 02 - DOOR AND LATCH PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8540108			Clamp, Bellow To Tub
2	8540952	W10111435		Bellow
3	8540772	W10253483		Lock, Door
4	8540725			Screw
5	8540221	W10111148		Strike
6	8540533			Trim Ring, Outer Door
7	8540107	W10217563		Clamp, Bellow To Front Panel
8	8540115			Clamp, Support
9	8540114			Clamp, Glass
10	8540513	8182214		Screw
11	8540588			Frame, Door Front Assembly
12	8540428	W10388315		Glass, Door
13	W10138523			Frame, Door Back Support
14	8540416	W10118967		Hinge, Door
15	8540284	8181660		Screw
16	8540282	8181661		Screw, Actuator

