


Whirlpool WFW8300SW04 04 - DISPENSER PARTS

DISPENSER PARTS

For Model: WFW8300SW04
(White/Grey)



W10205674

5

Whirlpool [Residential Whirlpool WFW8300SW04 Washer Parts](#) Parts Diagram 04 - DISPENSER PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8540751			Valve, Water Inlet
2	8540065			Hose, Valve To Dispenser
3	370450	596669		Clamp, Manifold
4	8540282	8181661		Screw, Actuator
5	8540042	8183181		Nozzle, Inlet
6	8540393			Cam, Actuator
7	8540394			Lever, Water Distribution
8	W10143587	W10143586		Actuator
9	8540400	8181721		Hook, Drawer
10	8281276			Clamp, Hose
11	8540395			Connection, Lever
12	8540058			Dispenser
13	8540053			Nozzle, Distribution
14	8540063			Hose, Dispenser To Tub
15	8571947			Handle, Drawer
16	W10117943	8303811		Badge, Assembly

