


Whirlpool WFW8400TB00 03 - CONTROL PANEL PARTS

CONTROL PANEL PARTS

For Models: WFW8400TW00, WFW8400TB00
(White) (Black)



4

W10139064

Whirlpool Residential Whirlpool WFW8400TB00 Washer Parts Parts Diagram 03 - CONTROL PANEL PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10132001			Panel, Control
"	W10131963			Panel, Control
2	8574963			Knob, Control
"	W10129067			Knob, Control
3	8574920			User Interface
"	W10149382			User Interface
4	8540558	W10240776		Brace, Top Front
5	8540839			Channel, Water
6	W10160253	W10205841		Control-Elec
7	3390647	488729		Screw
8	8540524	W10184856		Harness, Wiring
9	8540282	8181661		Screw, Actuator
10	W10015090	489442		Screw 3 2217757 Roller, Front