


# Whirlpool WFW8400TW00 03 - CONTROL PANEL PARTS

## CONTROL PANEL PARTS

For Models: WFW8400TW00, WFW8400TB00  
(White) (Black)



4

W10139064

Whirlpool Residential Whirlpool WFW8400TW00 Washer Parts Parts Diagram 03 - CONTROL PANEL PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">W10132001</a>			Panel, Control
"	<a href="#">W10131963</a>			Panel, Control
2	<a href="#">8574963</a>			Knob, Control
"	<a href="#">W10129067</a>			Knob, Control
3	<a href="#">8574920</a>			User Interface
"	<a href="#">W10149382</a>			User Interface
4	8540558	<a href="#">W10240776</a>		Brace, Top Front
5	<a href="#">8540839</a>			Channel, Water
6	W10160253	<a href="#">W10205841</a>		Control-Elec
7	3390647	<a href="#">488729</a>		Screw
8	8540524	<a href="#">W10184856</a>		Harness, Wiring
9	8540282	<a href="#">8181661</a>		Screw, Actuator
10	W10015090	<a href="#">489442</a>		Screw 3 2217757 Roller, Front