


**DISPENSER PARTS**

For Model: WFW8410SW01  
(White/Grey)



W10121971

5

Whirlpool [Residential Whirlpool WFW8410SW01 Washer Parts](#) Parts Diagram 04 - DISPENSER PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">8540751</a>			Valve, Water Inlet
2	<a href="#">8540065</a>			Hose, Valve To Dispenser
3	370450	<a href="#">596669</a>		Clamp, Manifold
4	8540282	<a href="#">8181661</a>		Screw, Actuator
5	8540042	<a href="#">8183181</a>		Nozzle, Inlet
6	<a href="#">8540393</a>			Cam, Actuator
7	<a href="#">8540394</a>			Lever, Water Distribution
8	8540041	<a href="#">W10143586</a>		Actuator
9	VS611	<a href="#">8526417</a>		Washer
10	<a href="#">8281276</a>			Clamp, Hose
11	<a href="#">8540395</a>			Connection, Lever
12	<a href="#">8540058</a>			Dispenser
13	<a href="#">8540053</a>			Nozzle, Distribution
14	<a href="#">8540063</a>			Hose, Dispenser To Tub
15	<a href="#">8571947</a>			Handle, Drawer
16	<a href="#">8303811</a>			Badge, Assembly

17	<a href="#">8540402</a>		Drawer, Detergent
18	<a href="#">8540399</a>		Cover, Detergent Drawer
19	<a href="#">8540429</a>		Siphon, Bleach/Softener
20	8540400	<a href="#">8181721</a>	Hook, Drawer

