


Whirlpool WFW8410SW03 03 - CONTROL PANEL PARTS



4

W10238202

Whirlpool [Residential Whirlpool WFW8410SW03 Washer Parts](#) Parts Diagram 03 - CONTROL PANEL PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10099594			Panel, Control
2	8574963			Knob, Control
3	8571919			User Interface
4	W10161692	W10240776		Brace, Top Front
5	8540839			Channel, Water
6	W10217411	W10246291		Control-Elec
7	3390647	488729		Screw
8	W10201875			Harness, Wiring
9	8540282	8181661		Screw, Actuator
10	W10015090	489442		Screw 3 2217757 Roller, Front