


Whirlpool WFW9050XW01 02 - DOOR AND LATCH PARTS

DOOR AND LATCH PARTS

For Model: WFW9050XW01

(White)



W10387246

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

3

Whirlpool [Residential Whirlpool WFW9050XW01 Washer Parts](#) Parts Diagram 02 - DOOR AND LATCH PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10290499	W10381562		Bellow
2	8540108			Clamp, Bellow To Tub
3	W10253483			Lock, Door
4	8540725			Screw
5	8540221	W10111148		Strike
6	W10217563			Clamp, Bellow To Front Panel
7	W10300867			Frame Assembly, Door Front
8	W10300865			Handle, Door
9	8540282	8181661		Screw, Actuator
10	8540513	8182214		Screw
11	W10205548	W10387885		Glass, Door
12	W10207904			Frame, Door Back Support
13	W10210893			Hinge, Door
14	W10015090	489442		Screw 3 2217757 Roller, Front