


Whirlpool WFW9150WW01 02 - DOOR AND LATCH PARTS

DOOR AND LATCH PARTS

For Model: WFW9150WW01

(White)



W10315508

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

3

Whirlpool [Residential Whirlpool WFW9150WW01 Washer Parts](#) Parts Diagram 02 - DOOR AND LATCH PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	8540108			Clamp, Bellow To Tub
2	W10290499	W10381562		Bellow
3	W10253483			Lock, Door
4	8540725			Screw
5	8540221	W10111148		Strike
6	W10209545			Trim Ring, Outer Door
7	W10217563			Clamp, Bellow To Front Panel
8	8540115			Clamp, Support
9	8540282	8181661		Screw, Actuator
10	8540513	8182214		Screw
11	W10344525			Door Assembly
12	W10387885			Glass, Door
13	W10015090	489442		Screw 3 2217757 Roller, Front