


Whirlpool WFW9250WL01 02 - DOOR AND LATCH PARTS

DOOR AND LATCH PARTS

For Models: WFW9250WW01, WFW9250WR01, WFW9250WL01
(White) (Red) (Silver)



Whirlpool [Residential Whirlpool WFW9250WL01 Washer Parts](#) Parts Diagram 02 - DOOR AND LATCH PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8540108			Clamp, Bellow To Tub
2	W10290499	W10381562		Bellow
3	W10253483			Lock, Door
4	8540725			Screw
5	8540221	W10111148		Strike
6	W10209545			Trim Ring, Outer Door
"	W10248152			Trim Ring, Outer Door
"	W10248151			Trim Ring, Outer Door
7	W10217563			Clamp, Bellow To Front Panel
8	8540115			Clamp, Support
9	8540114			Clamp, Glass
10	8540513	8182214		Screw
11	W10209537			Frame, Door Front Assembly
12	W10205548	W10387885		Glass, Door
13	W10240989			Frame, Door Back Support
14	W10118967			Hinge, Door

15 8540284
16 8540282
17 W10015090

[8181660](#)
[8181661](#)
[489442](#)

Screw
Screw, Actuator
Screw 3 2217757 Roller, Front

