


# Whirlpool WFW9250WR00 02 - DOOR AND LATCH PARTS

## DOOR AND LATCH PARTS

For Models: WFW9250WW00, WFW9250WR00, WFW9250WL00  
(White) (Red) (Silver)



Whirlpool [Residential Whirlpool WFW9250WR00 Washer Parts](#) Parts Diagram 02 - DOOR AND LATCH PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">8540108</a>			Clamp, Bellow To Tub
2	W10290499	<a href="#">W10381562</a>		Bellow
3	8540772	<a href="#">W10253483</a>		Lock, Door
4	<a href="#">8540725</a>			Screw
5	8540221	<a href="#">W10111148</a>		Strike
6	<a href="#">W10209545</a>			Trim Ring, Outer Door
"	<a href="#">W10248152</a>			Trim Ring, Outer Door
"	<a href="#">W10248151</a>			Trim Ring, Outer Door
7	W10277975	<a href="#">W10217563</a>		Clamp, Bellow To Front Panel
8	<a href="#">8540115</a>			Clamp, Support
9	<a href="#">8540114</a>			Clamp, Glass
10	8540513	<a href="#">8182214</a>		Screw
11	<a href="#">W10209537</a>			Frame, Door Front Assembly
12	W10205548	<a href="#">W10387885</a>		Glass, Door
13	<a href="#">W10240989</a>			Frame, Door Back Support
14	8540416	<a href="#">W10118967</a>		Hinge, Door

15	8540284	<a href="#">8181660</a>	Screw
16	8540282	<a href="#">8181661</a>	Screw, Actuator
17	W10015090	<a href="#">489442</a>	Screw 3 2217757 Roller, Front

