


Whirlpool WFW9250WR01 03 - CONTROL PANEL PARTS



4

W10315509

[Whirlpool Residential Whirlpool WFW9250WR01 Washer Parts](#) Parts Diagram 03 - CONTROL PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10325313			Console
"	W10253387			Console
"	W10325314			Console
2	W10237305			Cover, Center
"	W10272152			Cover, Center
"	W10272146			Cover, Center
3	W10215781			Knob Assembly
"	W10247262			Knob Assembly
4	W10237301			Cycle, Light Guide
5	W10212769	W10402922		Control-Elec
6	W10006580			Screw, M3-1.12 X12 Pn 6l Spl
7	W10240776			Brace, Top Front
8	8540839			Channel, Water
9	W10309219			Microcomputer, Machine Control
10	W10298263			Harness, Wiring
11	8540282	8181661		Screw, Actuator

