


Whirlpool WFW9400SB02 03 - CONTROL PANEL PARTS

CONTROL PANEL PARTS

For Models: WFW9400SW02, WFW9400SB02, WFW9400ST02, WFW9400SZ02, WFW9400SU02
(White/Chrome) (Black/Chrome) (Biscuit/Gold) (White/Blue) (Ultimate Silver)



Whirlpool [Residential Whirlpool WFW9400SB02 Washer Parts](#) Parts Diagram 03 - CONTROL PANEL PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8183229			Panel, Control
"	8183230			Panel, Control
"	8183231			Panel, Control
"	8183232			Panel, Control
"	8183233			Panel, Control
2	W10131369			Knob, Control
"	W10131370			Knob, Control
"	W10131372			Knob, Control
"	W10131373			Knob, Control
"	W10131371			Knob, Control
3	W10133927			Wheel, Detent Kit
4	W10131661	W10133927		Wheel, Detent Kit
5	W10131377	W10133927		Wheel, Detent Kit
6	W10131378	W10133927		Wheel, Detent Kit
7	W10131376	W10012410		Knob, Light Ring
8	W10131381			Wheel, Encoder

9	W10131382	W10012440	Retainer-Snap
10	W10164402		User Interface, Center
11	8183177		Adapter, Encoder Wheel
12	W10191964	W10319813	Control-Elec
13	W10168511	8183254	Harness, Wiring
14	8183259		Microcomputer, Machine Control
15	8183203	W10059240	Brace, Front Top
16	8183204		Channel, Water
17	8181756	488729	Screw
18	8183266		Harness, Wiring

Howes
the laundry company[®]

Howes
the laundry company[®]

Howes
the laundry company[®]