


Whirlpool WFW9400ST01 04 - DISPENSER PARTS

DISPENSER PARTS

For Models: WFW9400SW01, WFW9400SB01, WFW9400ST01, WFW9400SZ01, WFW9400SU01
(White/Chrome) (Black/Chrome) (Biscuit/Gold) (White/Blue) (Ultimate Silver)



W10169558

5

Whirlpool [Residential Whirlpool WFW9400ST01 Washer Parts](#) Parts Diagram 04 - DISPENSER PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8182862			Valve, Inlet
2	8183182			Hose, Flowmeter
3	8181751	489503		Clamp
4	8181696	W10110225		Flowmeter
5	8183180			Hose, Inlet Nozzle
6	8183181			Nozzle, Inlet
7	8183183			Lever, Water Distribution
8	8183184			Cam, Actuator
9	8183185	W10161052		Lever, Water Distribution
10	8183186	W10352973		Actuator
11	8181661			Screw, Actuator
12	W10164400			Plate, Distribution
13	8181712			Nozzle, Distribution
14	8181721			Hook, Drawer
15	W10121596			Separator, With Selection Slider
16	W10121861			Syphon, Bleach/Softener

17	8183179		Cover, Detergent Drawer
18	8183174		Drawer, Detergent
19	W10156617		Bracket, Handle Fixation
20	8183234	280214	Handle
"	8183235	280215	Handle
"	8183236	280216	Handle
"	8183237	280217	Handle
21	8183253		Medallion
22	8182214		Screw
23	8181747		Seal
24	8181718		Tube, Dispenser To Bellow
25	W10169232		Dispenser, Complete

the laundry company[®]

the laundry company[®]

the laundry company[®]