


Whirlpool WFW9400SU00 03 - CONTROL PANEL PARTS

CONTROL PANEL PARTS

For Models: WFW9400SW00, WFW9400SB00, WFW9400ST00, WFW9400SZ00, WFW9400SU00
(White/Chrome) (Black/Chrome) (Biscuit/Gold) (White/Blue) (Ultimate Silver)



Whirlpool [Residential Whirlpool WFW9400SU00 Washer Parts](#) Parts Diagram 03 - CONTROL PANEL PARTS

[Click on the part number to view part](#)

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|---------------------------|---------------------------|--------|-------------------|
| 1 | 8183229 | | | Panel, Control |
| " | 8183230 | | | Panel, Control |
| " | 8183231 | | | Panel, Control |
| " | 8183232 | | | Panel, Control |
| " | 8183233 | | | Panel, Control |
| 2 | W10131369 | | | Knob, Control |
| " | W10131370 | | | Knob, Control |
| " | W10131372 | | | Knob, Control |
| " | W10131373 | | | Knob, Control |
| " | W10131371 | | | Knob, Control |
| 3 | W10133927 | | | Wheel, Detent Kit |
| 4 | W10131661 | W10133927 | | Wheel, Detent Kit |
| 5 | W10131377 | W10133927 | | Wheel, Detent Kit |
| 6 | W10131378 | W10133927 | | Wheel, Detent Kit |
| 7 | W10131376 | W10012410 | | Knob, Light Ring |
| 8 | W10131381 | | | Wheel, Encoder |

| | | | |
|----|-------------------------|---------------------------|--------------------------------|
| 9 | W10131382 | W10012440 | Retainer-Snap |
| 10 | 8183262 | W10164402 | User Interface, Center |
| 11 | 8183177 | | Adapter, Encoder Wheel |
| 12 | 8183263 | W10319813 | Control-Elec |
| 13 | 8183254 | | Harness, Wiring |
| 14 | 8183259 | | Microcomputer, Machine Control |
| 15 | 8183203 | W10059240 | Brace, Front Top |
| 16 | 8183204 | | Channel, Water |
| 17 | 8181756 | 488729 | Screw |
| 18 | 8183266 | | Harness, Wiring |

