


# Whirlpool WFW9400SW00 03 - CONTROL PANEL PARTS

## CONTROL PANEL PARTS

For Models: WFW9400SW00, WFW9400SB00, WFW9400ST00, WFW9400SZ00, WFW9400SU00  
(White/Chrome) (Black/Chrome) (Biscuit/Gold) (White/Blue) (Ultimate Silver)



[Whirlpool Residential Whirlpool WFW9400SW00 Washer Parts](#) Parts Diagram 03 - CONTROL PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">8183229</a>			Panel, Control
"	<a href="#">8183230</a>			Panel, Control
"	<a href="#">8183231</a>			Panel, Control
"	<a href="#">8183232</a>			Panel, Control
"	<a href="#">8183233</a>			Panel, Control
2	<a href="#">W10131369</a>			Knob, Control
"	<a href="#">W10131370</a>			Knob, Control
"	<a href="#">W10131372</a>			Knob, Control
"	<a href="#">W10131373</a>			Knob, Control
"	<a href="#">W10131371</a>			Knob, Control
3	<a href="#">W10133927</a>			Wheel, Detent Kit
4	W10131661	<a href="#">W10133927</a>		Wheel, Detent Kit
5	W10131377	<a href="#">W10133927</a>		Wheel, Detent Kit
6	W10131378	<a href="#">W10133927</a>		Wheel, Detent Kit
7	W10131376	<a href="#">W10012410</a>		Knob, Light Ring
8	<a href="#">W10131381</a>			Wheel, Encoder

9	W10131382	<a href="#">W10012440</a>	Retainer-Snap
10	8183262	<a href="#">W10164402</a>	User Interface, Center
11	<a href="#">8183177</a>		Adapter, Encoder Wheel
12	8183263	<a href="#">W10319813</a>	Control-Elec
13	<a href="#">8183254</a>		Harness, Wiring
14	<a href="#">8183259</a>		Microcomputer, Machine Control
15	8183203	<a href="#">W10059240</a>	Brace, Front Top
16	<a href="#">8183204</a>		Channel, Water
17	8181756	<a href="#">488729</a>	Screw
18	<a href="#">8183266</a>		Harness, Wiring

