


Whirlpool WFW9400SW04 03 - CONTROL PANEL PARTS

CONTROL PANEL PARTS

For Models: WFW9400SW04, WFW9400SZ04
(White/Chrome) (White/Blue)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

4

W10313013

[Whirlpool Residential Whirlpool WFW9400SW04 Washer Parts](#) Parts Diagram 03 - CONTROL PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	8183229			Panel, Control
"	8183232			Panel, Control
2	W10131369			Knob, Control
"	W10131373			Knob, Control
3	W10133927			Wheel, Detent Kit
4	W10131661	W10133927		Wheel, Detent Kit
5	W10131377	W10133927		Wheel, Detent Kit
6	W10131378	W10133927		Wheel, Detent Kit
7	W10131376	W10012410		Knob, Light Ring
8	W10131381			Wheel, Encoder
9	W10131382	W10012440		Retainer-Snap
10	W10164402			User Interface, Center
11	8183177			Adapter, Encoder Wheel
12	W10191964	W10319813		Control-Elec
13	W10283465			Harness, Wiring
14	W10271606			Microcomputer, Machine Control

15	8183203	W10059240	Brace, Front Top
16	8183204		Channel, Water
17	8181756	488729	Screw
18	W10271603		Harness, Wiring

