


Whirlpool WFW9400SWA10 01 - TOP AND CABINET PARTS



Whirlpool Residential Whirlpool WFW9400SWA10 Washer Parts Parts Diagram 01 - TOP AND CABINET PARTS
Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|---------------------------|---------------------------|---------------|-------------------------------|
| 1 | 8183052 | | | Use And Care Guide |
| " | 8183018 | | Not Available | Tech Sheet |
| " | W10114111 | | Not Available | Energy Guide |
| " | 8183017 | | Not Available | Quick Start Guide |
| 2 | W10068780 | 8183223 | | Trim Ring, Teardrop Assembly |
| " | W10068820 | 8183225 | | Trim Ring, Teardrop Assembly |
| " | W10068790 | 8183224 | | Trim Ring, Teardrop Assembly |
| " | W10068830 | 8183226 | | Trim Ring, Teardrop Assembly |
| 3 | W10015770 | 8183208 | | Bracket, Trim Fixation |
| 4 | W10015780 | 8183209 | | Bracket, Trim Fixation |
| 5 | W10029650 | 8183210 | | Clip, Trim |
| 6 | W10015090 | 489442 | | Screw 3 2217757 Roller, Front |
| 7 | W10003640 | 8181643 | | Toe Panel |
| " | W10115651 | | | Toe Panel |
| " | W10115654 | | Not Available | Toe Panel (Biscuit) |
| 8 | W10015580 | W10015590 | | Panel |

| | | | |
|----|---------------------------|----------------------------|---|
| " | W10116514 | | Panel, Front |
| " | W10116515 | Not Available | Panel, Front (Biscuit) |
| 9 | W10116562 | | Harness, Wiring |
| 10 | W10003460 | W10216383 | Channel, Harness |
| 11 | W10047920 | W10168549 | Channel, Harness |
| 12 | W10003920 | W10003900 | Top |
| " | W10115611 | Not Available | Top (Black) |
| " | W10115612 | Not Available | Top (Biscuit) |
| 13 | W10002880 | | Cabinet |
| " | W10117088 | | Cabinet |
| " | W10117089 | Not Available | Cabinet (Biscuit) |
| 14 | W10003290 | 8182209 | Retainer, Drain Hose |
| 15 | W10065150 | W10163982 | Switch, Pressure |
| 16 | W10008890 | 8181763 | Bracket, Spring |
| 17 | W10004260 | | Hose, Pressure Switch |
| 18 | W10003250 | | Hose, Drain-Inner |
| 19 | W10004320 | | Sleeve, Drain Hose |
| 20 | W10015480 | W10384846 | Motor Control Unit |
| 21 | 8540210 | W10085220 | Microswitch |
| 22 | 8540479 | | Screw, Grounding |
| 23 | W10064810 | | Foot, Leveling |
| 24 | W10110674 | 8183009 | Cord, Power |
| 25 | W10110676 | 8182635 | Strain Relief |
| 26 | W10022290 | 8182702 | Clip, Outer Hose Holder |
| 27 | W10003260 | 8181738 | Connector, Hose Outlet |
| 28 | 356138 | | Clamp, Hose |
| 29 | W10110677 | | Brace, Rear |
| 30 | 8540230 | W10339736 | Filter, Interference |
| 31 | W10003280 | 8181737 | Hose, Drain |
| 32 | 16123 | | Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately. |
| 33 | 8540021 | W10280024 | U-Bend, Drain Hose |
| 34 | 8571377 | 89503 | Hose-Inlet |
| " | 8571378 | 89503 | Hose-Inlet |
| 35 | 3347868 | W10339879 | Tie, Cable |
| 36 | 8540727 | 8182201 | Screw, 3 X 8 mm |
| 37 | 8540728 | 8182699 | Grommet, Cord Support |
| 38 | 8540268 | | Cover, Transport |
| 39 | W10003270 | 8182701 | Clip, Outer Hose Holder |
| 40 | W10003030 | | Panel, Rear |
| 41 | W10003040 | | Brace, Transport |
| 42 | W10003340 | W10289554A | Bolt |
| " | W10003350 | W10289554A | Bolt |
| 43 | W10123373 | | Spacer, Top |
| 44 | 8283273 | | Damper, Brace |
| 45 | 8540720 | | Brace, Top |