


Whirlpool WFW9400SWA10 04 - DISPENSER PARTS



W10130064

5

Whirlpool [Residential Whirlpool WFW9400SWA10 Washer Parts](#) Parts Diagram 04 - DISPENSER PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8540282	8181661		Screw, Actuator
2	8540751			Valve, Water Inlet
3	370450	596669		Clamp, Manifold
4	W10003220			Hose, Flowmeter And Valve
5	W10110225			Flowmeter
6	8540042	8183181		Nozzle, Inlet
7	W10003830	8183183		Lever, Water Distribution
8	W10003190	8183184		Cam, Actuator
9	W10003180	W10161052		Lever, Water Distribution
10	W10065190	W10352973		Actuator
11	W10015450			Dispenser, Complete
12	W10005080	W10164400		Plate, Distribution
13	W10003110	8181712		Nozzle, Distribution
14	W10003170	8181721		Hook, Drawer
15	W10015200	W10121596		Separator, With Selection Slider
16	W10009120			Syphon, Bleach/Softener

17	W10003140	8183179	Cover, Detergent Drawer
18	W10114234		Drawer, Detergent
19	8183238	W10156617	Bracket, Handle Fixation
20	8183234	280214	Handle
"	8183235	280215	Handle
"	8183236	280216	Handle
21	3956001	8183253	Medallion
22	W10003360	8181747	Seal
23	W10005300	8181718	Tube, Dispenser To Bellow

