


# Whirlpool WFW9400SZ00 04 - DISPENSER PARTS

## DISPENSER PARTS

For Models: WFW9400SW00, WFW9400SB00, WFW9400ST00, WFW9400SZ00, WFW9400SU00  
(White/Chrome) (Black/Chrome) (Biscuit/Gold) (White/Blue) (Ultimate Silver)



W10121846

5

Whirlpool [Residential Whirlpool WFW9400SZ00 Washer Parts](#) Parts Diagram 04 - DISPENSER PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">8182862</a>			Valve, Inlet
2	<a href="#">8183182</a>			Hose, Flowmeter
3	8181751	<a href="#">489503</a>		Clamp
4	8181696	<a href="#">W10110225</a>		Flowmeter
5	<a href="#">8183180</a>			Hose, Inlet Nozzle
6	<a href="#">8183181</a>			Nozzle, Inlet
7	<a href="#">8183183</a>			Lever, Water Distribution
8	<a href="#">8183184</a>			Cam, Actuator
9	8183185	<a href="#">W10161052</a>		Lever, Water Distribution
10	8183186	<a href="#">W10352973</a>		Actuator
11	<a href="#">8181661</a>			Screw, Actuator
12	8183178	<a href="#">W10164400</a>		Plate, Distribution
13	<a href="#">8181712</a>			Nozzle, Distribution
14	<a href="#">8181721</a>			Hook, Drawer
15	<a href="#">W10121596</a>			Separator, With Selection Slider
16	<a href="#">W10121861</a>			Syphon, Bleach/Softener

17	<a href="#">8183179</a>		Cover, Detergent Drawer
18	<a href="#">8183174</a>		Drawer, Detergent
19	8183238	<a href="#">W10156617</a>	Bracket, Handle Fixation
20	8183234	<a href="#">280214</a>	Handle
"	8183235	<a href="#">280215</a>	Handle
"	8183236	<a href="#">280216</a>	Handle
"	8183237	<a href="#">280217</a>	Handle
21	<a href="#">8183253</a>		Medallion
22	<a href="#">8182214</a>		Screw
23	<a href="#">8181747</a>		Seal
24	<a href="#">8181718</a>		Tube, Dispenser To Bellow
25	8183176	<a href="#">W10169232</a>	Dispenser, Complete

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>