


# Whirlpool WFW9400SZ02 02 - DOOR AND LATCH PARTS

## DOOR AND LATCH PARTS

For Models: WFW9400SW02, WFW9400SB02, WFW9400ST02, WFW9400SZ02, WFW9400SU02  
(White/Chrome) (Black/Chrome) (Biscuit/Gold) (White/Blue) (Ultimate Silver)



W10252274

3

Whirlpool [Residential Whirlpool WFW9400SZ02 Washer Parts](#) Parts Diagram 02 - DOOR AND LATCH PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">8182210</a>			Clamp, Bellow
2	<a href="#">8182119</a>			Bellow
3	<a href="#">8183270</a>			Lock, Door
4	<a href="#">8182211</a>			Clamp, Bellow To Front Panel
5	8181760	<a href="#">8540725</a>		Screw
6	8183198	<a href="#">W10217552</a>		Hook, Door
7	8181758	<a href="#">8182214</a>		Screw
8	<a href="#">8181661</a>			Screw, Actuator
9	<a href="#">8181660</a>			Screw
10	<a href="#">8183195</a>			Frame, Door Back Support
11	8181659	<a href="#">W10128586</a>		Clamp, Glass Support
12	<a href="#">8181655</a>			Glass, Door
13	<a href="#">8183202</a>			Hinge, Door
14	8183199	<a href="#">W10295703</a>		Clamp, Glass
15	<a href="#">8183256</a>			Frame, Door Front Support
16	<a href="#">8183255</a>			Screen, Door

17	W10189784	<a href="#">W10069120</a>	Trim Ring, Outer Door
"	W10189786	<a href="#">W10069160</a>	Ring-Trim
"	W10189787	<a href="#">W10069150</a>	Ring-Trim

