


Whirlpool WFW9400SZA10 06 - PUMP AND MOTOR PARTS, OPTIONAL PARTS (NOT INCLUDED)

PUMP AND MOTOR PARTS

For Models: WFW9400SWA10, WFW9400SBA10, WFW9400STA10, WFW9400SZA10
(White/Chrome) (Black/Chrome) (Biscuit/Gold) (White/Blue)



W10130064

9

Whirlpool [Residential Whirlpool WFW9400SZA10 Washer Parts](#) Parts Diagram 06 - PUMP AND MOTOR PARTS, OPTIONAL PARTS (NOT INCLUDED).
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10116561			Harness, Motor
2	W10004230	W10140583		Motor, Drive
3	8540134			Bolt, Motor
4	W10003330	W10121657		Ball
5	8540008			Clamp
6	W10003240	8181732		Hose, Tub To Pump
7	356138			Clamp, Hose
8	370448	616099		Clamp
9	W10117829	W10130913		Pump
10	W10034820			Foot, Rubber
11	W10034830			Foot, Rubber
12	8540033			Cap, Right Foot
13	8533964			Screw, 10-16 X 1.25
14	8540025	W10130913		Pump
15	8540996	W10130913		Pump

	72017		Paint, Touch-Up
"	72032		Paint, Touch-Up
"	4392899		Paint, Touch-Up
"	350938		Paint, Pressurized Spray B
"	350930		Paint, Pressurized Spray B
"	786020	Not Available	PAINT, PRESSURIZED SPRAY (12 oz.) (Black)
"	4392901		Paint, Pressurized Spray
"	799344		Paint, Touch-Up)
"	786032		Refinishing Material
"	4392900		Paint, Bulk)
"	BLANK	Not Available	ACCESSORY PARTS
"	285863		Water System Parts

