


Whirlpool WFW9450WW00 04 - DISPENSER PARTS



Whirlpool [Residential Whirlpool WFW9450WW00 Washer Parts](#) Parts Diagram 04 - DISPENSER PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8540282	8181661		Screw, Actuator
2	8540751			Valve, Water Inlet
3	370450	596669		Clamp, Manifold
4	8540065			Hose, Valve To Dispenser
5	8540042	8183181		Nozzle, Inlet
6	W10003830	8183183		Lever, Water Distribution
7	W10003190	8183184		Cam, Actuator
8	W10003180	W10161052		Lever, Water Distribution
9	W10163975	W10352973		Actuator
10	W10074160	W10157886		Dispenser, Complete
11	W10005080	W10164400		Plate, Distribution
12	W10003110	8181712		Nozzle, Distribution
13	W10003170	8181721		Hook, Drawer
14	W10015200	W10121596		Separator, With Selection Slider
15	W10003150	W10121598		Syphon, Bleach/Softener
16	W10003140	8183179		Cover, Detergent Drawer

17	W10015190	8183173	Drawer, Detergent
18	W10156617		Bracket, Handle Fixation
19	W10251722	W10256728	Handle
"	W10251720	W10256729	Handle
"	W10251719	W10256730	Handle
20	3400981	8183253	Medallion
21	W10003360	8181747	Seal
22	W10005300	8181718	Tube, Dispenser To Bellow

