


Whirlpool WFW9470WL00 04 - DISPENSER PARTS



Whirlpool [Residential Whirlpool WFW9470WL00 Washer Parts](#) Parts Diagram 04 - DISPENSER PARTS
Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|---------------------------|---------------------------|--------|----------------------------------|
| 1 | W10289387 | | | Valve, Water Inlet |
| 2 | W10291582 | | | Hose, Inlet Valve To Dispenser |
| 3 | 8181751 | 489503 | | Clamp |
| 4 | 8183181 | | | Nozzle, Inlet |
| 5 | 8181718 | | | Tube, Dispenser To Bellow |
| 6 | 8183183 | | | Lever, Water Distribution |
| 7 | 8183184 | | | Cam, Actuator |
| 8 | W10161052 | | | Lever, Water Distribution |
| 9 | 8181661 | | | Screw, Actuator |
| 10 | W10283468 | W10352973 | | Actuator |
| 11 | W10157886 | | | Dispenser, Complete |
| 12 | W10164400 | | | Plate, Distribution |
| 13 | 8181712 | | | Nozzle, Distribution |
| 14 | 8181721 | | | Hook, Drawer |
| 15 | W10121596 | | | Separator, With Selection Slider |

| | | | |
|----|---------------------------|---------------------------|--------------------------|
| 16 | W10121598 | | Syphon, Bleach/Softener |
| 17 | 8183179 | | Cover, Detergent Drawer |
| 18 | 8183173 | | Drawer, Detergent |
| 19 | W10156617 | | Bracket, Handle Fixation |
| 20 | W10296484 | W10296491 | Handle |
| " | W10296485 | W10296492 | Handle |
| " | W10296486 | W10296493 | Handle |
| 21 | 8183253 | | Medallion |
| 22 | 8181747 | | Seal |

