


# Whirlpool WFW9470WL01 04 - DISPENSER PARTS



Whirlpool [Residential Whirlpool WFW9470WL01 Washer Parts](#) Parts Diagram 04 - DISPENSER PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">W10289387</a>			Valve, Water Inlet
2	<a href="#">W10291582</a>			Hose, Inlet Valve To Dispenser
3	8181751	<a href="#">489503</a>		Clamp
4	<a href="#">8183181</a>			Nozzle, Inlet
5	<a href="#">8181718</a>			Tube, Dispenser To Bellow
6	<a href="#">8183183</a>			Lever, Water Distribution
7	<a href="#">8183184</a>			Cam, Actuator
8	<a href="#">W10161052</a>			Lever, Water Distribution
9	<a href="#">8181661</a>			Screw, Actuator
10	W10283468	<a href="#">W10352973</a>		Actuator
11	<a href="#">W10157886</a>			Dispenser, Complete
12	<a href="#">W10164400</a>			Plate, Distribution
13	<a href="#">8181712</a>			Nozzle, Distribution
14	<a href="#">8181721</a>			Hook, Drawer
15	<a href="#">W10121596</a>			Separator, With Selection Slider

16	<a href="#">W10121598</a>		Syphon, Bleach/Softener
17	<a href="#">8183179</a>		Cover, Detergent Drawer
18	<a href="#">8183173</a>		Drawer, Detergent
19	<a href="#">W10156617</a>		Bracket, Handle Fixation
20	W10296484	<a href="#">W10296491</a>	Handle
"	W10296485	<a href="#">W10296492</a>	Handle
"	W10296486	<a href="#">W10296493</a>	Handle
21	<a href="#">8183253</a>		Medallion
22	<a href="#">8181747</a>		Seal

