


Whirlpool WFW9470WR00 03 - CONTROL PANEL PARTS

CONTROL PANEL PARTS

For Models: WFW9470WW00 (White), WFW9470WR00 (Red), WFW9470WL00 (Mercury Silver)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

[Whirlpool Residential Whirlpool WFW9470WR00 Washer Parts](#) Parts Diagram 03 - CONTROL PANEL PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10296481			Panel-Control
"	W10296482			Panel-Control
"	W10296483			Panel-Control
2	W10190685			Knob, Control
3	W10133927			Wheel, Detent Kit
4	W10131661	W10133927		Wheel, Detent Kit
5	W10131377	W10133927		Wheel, Detent Kit
6	W10131378	W10133927		Wheel, Detent Kit
7	W10131376	W10012410		Knob, Light Ring
8	W10131381			Wheel, Encoder
9	W10131382	W10012440		Retainer-Snap
10	W10283460			User Interface, Center
11	8183177			Adapter, Encoder Wheel
12	W10283462			User Interface, Right
13	W10283465			Harness, Wiring
14	W10283459			Microcomputer, Machine Control

15	8183203	W10059240	Brace, Front Top
16	8183204		Channel, Water
17	8181756	488729	Screw
18	W10283495		Harness, Wiring

