


Whirlpool WFW9470WR00 04 - DISPENSER PARTS



Whirlpool Residential Whirlpool WFW9470WR00 Washer Parts Parts Diagram 04 - DISPENSER PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10289387			Valve, Water Inlet
2	W10291582			Hose, Inlet Valve To Dispenser
3	8181751	489503		Clamp
4	8183181			Nozzle, Inlet
5	8181718			Tube, Dispenser To Bellow
6	8183183			Lever, Water Distribution
7	8183184			Cam, Actuator
8	W10161052			Lever, Water Distribution
9	8181661			Screw, Actuator
10	W10283468	W10352973		Actuator
11	W10157886			Dispenser, Complete
12	W10164400			Plate, Distribution
13	8181712			Nozzle, Distribution
14	8181721			Hook, Drawer
15	W10121596			Separator, With Selection Slider

16	W10121598		Syphon, Bleach/Softener
17	8183179		Cover, Detergent Drawer
18	8183173		Drawer, Detergent
19	W10156617		Bracket, Handle Fixation
20	W10296484	W10296491	Handle
"	W10296485	W10296492	Handle
"	W10296486	W10296493	Handle
21	8183253		Medallion
22	8181747		Seal

