


Whirlpool WFW9500TC01 03 - CONTROL PANEL PARTS

CONTROL PANEL PARTS

For Models: WFW9500TW01, WFW9500TC01
(White/Chrome) (Chestnut/Gold)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

4

W10188973

[Whirlpool Residential Whirlpool WFW9500TC01 Washer Parts](#) Parts Diagram 03 - CONTROL PANEL PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10180778			Panel, Control
"	W10180779			Panel, Control
2	W10131369			Knob, Control
"	W10166990			Knob, Control
3	W10133927			Wheel, Detent Kit
4	W10131661	W10133927		Wheel, Detent Kit
5	W10131377	W10133927		Wheel, Detent Kit
6	W10131378	W10133927		Wheel, Detent Kit
7	W10131376	W10012410		Knob, Light Ring
8	W10131381			Wheel, Encoder
9	W10131382	W10012440		Retainer-Snap
10	W10164402			User Interface, Center
11	8183177			Adapter, Encoder Wheel
12	W10180777	W10319815		Control-Elec
13	W10157884			Harness, Wiring
14	W10180782			Microcomputer, Machine Control

15	8183203	W10059240	Brace, Front Top
16	8183204		Channel, Water
17	8181756	488729	Screw
18	W10157883		Harness, Wiring

