


Whirlpool WFW9600TA00 03 - CONTROL PANEL PARTS



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

[Whirlpool Residential Whirlpool WFW9600TA00 Washer Parts](#) Parts Diagram 03 - CONTROL PANEL PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10157776			Panel, Control
"	W10157777		Not Available	Panel, Control (Black)
"	W10157799		Not Available	Panel, Control (White/Blue)
"	W10157800		Not Available	Panel, Control (Ultimate Silver)
"	W10157801			Panel, Control
"	W10157802		Not Available	Panel, Control (Chestnut)
2	W10131369			Knob, Control
"	W10131370			Knob, Control
"	W10131373			Knob, Control
"	W10131371			Knob, Control
"	W10166961			Knob, Control
"	W10166990			Knob, Control
3	W10133927			Wheel, Detent Kit
4	W10131661	W10133927		Wheel, Detent Kit
5	W10131377	W10133927		Wheel, Detent Kit
6	W10131378	W10133927		Wheel, Detent Kit

7	W10131376	W10012410	Knob, Light Ring
8	W10131381		Wheel, Encoder
9	W10131382	W10012440	Retainer-Snap
10	W10164402		User Interface, Center
11	8183177		Adapter, Encoder Wheel
12	W10157890	W10319814	Control-Elec
13	W10157884		Harness, Wiring
14	W10157913		Microcomputer, Machine Control
15	8183203	W10059240	Brace, Front Top
16	8183204		Channel, Water
17	8181756	488729	Screw
18	W10157883		Harness, Wiring

the laundry company[®]

the laundry company[®]

the laundry company[®]