


Whirlpool WFW9600TA02 01 - TOP AND CABINET PARTS



TOP AND CABINET PARTS

For Models: WFW9600TW02, WFW9600TA02
(White/Chrome)(Aspen/Chrome)

AUTOMATIC
WASHER



1-09 Printed in U.S.A. (drd)(bay)

1

Part No. W10249835 Rev. A

Whirlpool Residential Whirlpool WFW9600TA02 Washer Parts Parts Diagram 01 - TOP AND CABINET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10158198		Not Available	Use & Care Guide
"	W10250503		Not Available	Tech Sheet
"	W10222190		Not Available	Energy Guide
2	8181799	8181641		Top
"	W10166922			Top
3	W10250656			Cabinet
"	W10250659			Cabinet
4	8183151	W10015590		Panel
"	W10166920			Panel, Front
5	8181643			Toe Panel
"	W10166921			Toe Panel
6	W10160030			Trim Ring, Teardrop Assembly
"	W10160019			Trim Ring, Teardrop Assembly
7	8183208			Bracket, Trim Fixation
8	8183209			Bracket, Trim Fixation
9	8183210			Clip, Trim

10	W10250577		Harness, Wiring
11	8181636		Foot, Leveling
12	8182797	W10289554A	Bolt
"	8182798	W10289554A	Bolt
13	8182661	W10003040	Brace, Transport
14	W10242507		Panel, Rear
15	8181635		Pan, Bottom
16	W10250578		Brace, Rear
17	8181756	488729	Screw
18	W10121609		Channel, Harness
19	W10121610		Channel, Harness
20	W10249845		Switch, Analog Pressure Sensor
21	8181739	W10004260	Hose, Pressure Switch
22	8181763		Bracket, Spring
23	W10189678	W10085220	Microswitch
24	8181752	3367052	Clamp, Hose
25	8181738		Connector, Hose Outlet
26	8181737		Hose, Drain
27	8181690	8182635	Strain Relief
28	8183009		Cord, Power
29	8182702		Clip, Outer Hose Holder
30	8181768	W10280024	U-Bend, Drain Hose
31	8182699		Grommet, Cord Support
32	8182201		Screw, 3 X 8 mm
33	8182700	8540268	Cover, Transport
34	8182701		Clip, Outer Hose Holder
35	8181828	488729	Screw
36	8182795	89503	Hose-Inlet
"	8182792	89503	Hose-Inlet
37	8183019	W10326464	Filter, Interference
38	W10157885		Screw, 4.2 X 14
39	W10138249		Spacer, Top
40	8181632		Brace, Top

