


Whirlpool WFW9600TA02 03 - CONTROL PANEL PARTS

CONTROL PANEL PARTS

For Models: WFW9600TW02, WFW9600TA02
(White/Chrome)(Aspen/Chrome)



4

W10249835

[Whirlpool Residential Whirlpool WFW9600TA02 Washer Parts](#) Parts Diagram 03 - CONTROL PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10157776			Panel, Control
"	W10157801			Panel, Control
2	W10131369			Knob, Control
"	W10166961			Knob, Control
3	W10133927			Wheel, Detent Kit
4	W10131661	W10133927		Wheel, Detent Kit
5	W10131377	W10133927		Wheel, Detent Kit
6	W10131378	W10133927		Wheel, Detent Kit
7	W10131376	W10012410		Knob, Light Ring
8	W10131381			Wheel, Encoder
9	W10131382	W10012440		Retainer-Snap
10	W10164402			User Interface, Center
11	8183177			Adapter, Encoder Wheel
12	W10191963	W10319814		Control-Elec
13	W10250574			Harness, Wiring
14	W10249839		Not Available	Microcomputer, Machine Control

15	8183203	W10059240	Brace, Front Top
16	8183204		Channel, Water
17	8181756	488729	Screw
18	W10250575		Harness, Wiring

