


# Whirlpool WFW9600TZ00 03 - CONTROL PANEL PARTS



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

[Whirlpool Residential Whirlpool WFW9600TZ00 Washer Parts](#) Parts Diagram 03 - CONTROL PANEL PARTS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">W10157776</a>			Panel, Control
"	W10157777		Not Available	Panel, Control (Black)
"	W10157799		Not Available	Panel, Control (White/Blue)
"	W10157800		Not Available	Panel, Control (Ultimate Silver)
"	<a href="#">W10157801</a>			Panel, Control
"	W10157802		Not Available	Panel, Control (Chestnut)
2	<a href="#">W10131369</a>			Knob, Control
"	<a href="#">W10131370</a>			Knob, Control
"	<a href="#">W10131373</a>			Knob, Control
"	<a href="#">W10131371</a>			Knob, Control
"	<a href="#">W10166961</a>			Knob, Control
"	<a href="#">W10166990</a>			Knob, Control
3	<a href="#">W10133927</a>			Wheel, Detent Kit
4	W10131661	<a href="#">W10133927</a>		Wheel, Detent Kit
5	W10131377	<a href="#">W10133927</a>		Wheel, Detent Kit
6	W10131378	<a href="#">W10133927</a>		Wheel, Detent Kit

7	W10131376	<a href="#">W10012410</a>	Knob, Light Ring
8	<a href="#">W10131381</a>		Wheel, Encoder
9	W10131382	<a href="#">W10012440</a>	Retainer-Snap
10	<a href="#">W10164402</a>		User Interface, Center
11	<a href="#">8183177</a>		Adapter, Encoder Wheel
12	W10157890	<a href="#">W10319814</a>	Control-Elec
13	<a href="#">W10157884</a>		Harness, Wiring
14	<a href="#">W10157913</a>		Microcomputer, Machine Control
15	8183203	<a href="#">W10059240</a>	Brace, Front Top
16	<a href="#">8183204</a>		Channel, Water
17	8181756	<a href="#">488729</a>	Screw
18	<a href="#">W10157883</a>		Harness, Wiring

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>