


# Whirlpool WFW9630YL00 03 - CONTROL PANEL PARTS

## CONTROL PANEL PARTS

For Models: WFW9630YW00, WFW9630YL00  
(White) (Silver)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

4

W10412933

[Whirlpool Residential Whirlpool WFW9630YL00 Washer Parts](#) Parts Diagram 03 - CONTROL PANEL PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10418857		Not Available	PANEL, CONTROL (WHITE)
"	W10418863		Not Available	PANEL, CONTROL (SILVER)
2	<a href="#">W10190685</a>			Knob, Control
3	<a href="#">W10133927</a>			Wheel, Detent Kit
4	W10131661	<a href="#">W10133927</a>		Wheel, Detent Kit
5	W10131377	<a href="#">W10133927</a>		Wheel, Detent Kit
6	W10131378	<a href="#">W10133927</a>		Wheel, Detent Kit
7	W10131376	<a href="#">W10012410</a>		Knob, Light Ring
8	<a href="#">W10131381</a>			Wheel, Encoder
9	W10131382	<a href="#">W10012440</a>		Retainer-Snap
10	<a href="#">W10283460</a>			User Interface, Center
11	<a href="#">8183177</a>			Adapter, Encoder Wheel
12	W10362750		Not Available	USER INTERFACE, RIGHT
13	<a href="#">W10283465</a>			Harness, Wiring
14	W10404858		Not Available	MICROCOMPUTER, MACHINE CONTROL
15	8183203	<a href="#">W10059240</a>		Brace, Front Top

16 [8183204](#)

Channel, Water

17 8181756

[488729](#)

Screw

18 [W10411671](#)

Harness, Wiring

