


# Whirlpool WFW9700VA00 01 - TOP AND CABINET PARTS



11-08 Printed in U.S.A. (drd) (eeb)

1

Part No. W10208579 Rev. A

Whirlpool [Residential Whirlpool WFW9700VA00 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10176968		Not Available	Use & Care Guide
"	W10176957		Not Available	Tech Sheet
"	W10176960		Not Available	Energy Guide
2	W10176940	<a href="#">W10160030</a>		Trim Ring, Teardrop Assembly
"	W10176942	<a href="#">W10160019</a>		Trim Ring, Teardrop Assembly
3	W10015770	<a href="#">8183208</a>		Bracket, Trim Fixation
4	W10015780	<a href="#">8183209</a>		Bracket, Trim Fixation
5	W10029650	<a href="#">8183210</a>		Clip, Trim
6	W10015090	<a href="#">489442</a>		Screw 3 2217757 Roller, Front
7	W10003640	<a href="#">8181643</a>		Toe Panel
"	W10176923	<a href="#">W10166921</a>		Toe Panel
8	W10015580	<a href="#">W10015590</a>		Panel
"	W10176915	<a href="#">W10166920</a>		Panel, Front
9	<a href="#">W10167287</a>			Harness, Wiring
10	W10003460	<a href="#">W10216383</a>		Channel, Harness
11	W10131757	<a href="#">W10168549</a>		Channel, Harness

12	<a href="#">W10003900</a>		Top
"	W10176930	<a href="#">W10166922</a>	Top
13	<a href="#">W10171708</a>		Cabinet
"	<a href="#">W10176852</a>		Cabinet
14	<a href="#">W10156258</a>		Control Board, Expansion
15	<a href="#">W10249845</a>		Switch, Analog Pressure Sensor
16	W10008890	<a href="#">8181763</a>	Bracket, Spring
17	<a href="#">W10004260</a>		Hose, Pressure Switch
18	<a href="#">8540720</a>		Brace, Top
19	<a href="#">8283273</a>		Damper, Brace
20	<a href="#">3976348</a>		Absorber, Sound
21	<a href="#">W10085220</a>		Microswitch
22	<a href="#">8540479</a>		Screw, Grounding
23	<a href="#">W10064810</a>		Foot, Leveling
24	W10110674	<a href="#">8183009</a>	Cord, Power
25	W10110676	<a href="#">8182635</a>	Strain Relief
26	W10022290	<a href="#">8182702</a>	Clip, Outer Hose Holder
27	W10003260	<a href="#">8181738</a>	Connector, Hose Outlet
28	<a href="#">356138</a>		Clamp, Hose
29	<a href="#">W10110677</a>		Brace, Rear
30	8540230	<a href="#">W10339736</a>	Filter, Interference
31	W10003280	<a href="#">8181737</a>	Hose, Drain
32	<a href="#">16123</a>		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
33	8540021	<a href="#">W10280024</a>	U-Bend, Drain Hose
34	8571377	<a href="#">89503</a>	Hose-Inlet
"	8571378	<a href="#">89503</a>	Hose-Inlet
35	3347868	<a href="#">W10339879</a>	Tie, Cable
36	8540727	<a href="#">8182201</a>	Screw, 3 X 8 mm
37	8540728	<a href="#">8182699</a>	Grommet, Cord Support
38	<a href="#">8540268</a>		Cover, Transport
39	W10003270	<a href="#">8182701</a>	Clip, Outer Hose Holder
40	<a href="#">W10003030</a>		Panel, Rear
41	<a href="#">W10165710</a>		Brace, Transport
"	<a href="#">W10003040</a>		Brace, Transport
42	W10190006	<a href="#">W10243966</a>	Bolt
"	W10190007	<a href="#">W10243966</a>	Bolt

*the laundry company*<sup>®</sup>