


Whirlpool WFW9700VA00 03 - CONTROL PANEL PARTS

CONTROL PANEL PARTS

For Models: WFW9700VW00, WFW9700VA00
(White) (Aspen)



4

W10208579

Whirlpool [Residential Whirlpool WFW9700VA00 Washer Parts](#) Parts Diagram 03 - CONTROL PANEL PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10157776			Panel, Control
"	W10157801			Panel, Control
2	W10131369			Knob, Control
"	W10166961			Knob, Control
3	W10133927			Wheel, Detent Kit
4	W10131661	W10133927		Wheel, Detent Kit
5	W10131377	W10133927		Wheel, Detent Kit
6	W10131378	W10133927		Wheel, Detent Kit
7	W10131376	W10012410		Knob, Light Ring
8	W10131381			Wheel, Encoder
9	W10131382	W10012440		Retainer-Snap
10	W10164402			User Interface, Center
11	8183177			Adapter, Encoder Wheel
12	W10157890	W10319814		Control-Elec
13	W10157884			Harness, Wiring
14	W10175772			Microcomputer, Machine Control

15	W10059240		Brace, Front Top
16	W10003700	8183204	Channel, Water
17	W10015090	489442	Screw 3 2217757 Roller, Front
18	W10167278		Harness, Wiring

