


Whirlpool WFW9700VW01 04 - DISPENSER PARTS



W10245961

5

Whirlpool [Residential Whirlpool WFW9700VW01 Washer Parts](#) Parts Diagram 04 - DISPENSER PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8540282	8181661		Screw, Actuator
2	W10247305			Valve, Water Inlet
3	370450	596669		Clamp, Manifold
4	W10110225			Flowmeter
5	8540042	8183181		Nozzle, Inlet
6	W10003830	8183183		Lever, Water Distribution
7	W10003190	8183184		Cam, Actuator
8	W10161052			Lever, Water Distribution
9	W10163975	W10352973		Actuator
10	W10157759			Dispenser, Complete
11	W10005080	W10164400		Plate, Distribution
12	W10003110	8181712		Nozzle, Distribution
13	W10003170	8181721		Hook, Drawer
14	W10121596			Separator, With Selection Slider
15	W10157775			Syphon, Bleach/Softener
16	W10003140	8183179		Cover, Detergent Drawer

17	W10157760		Drawer, Detergent
18	W10156617		Bracket, Handle Fixation
19	W10156618	W10156625	Handle
"	W10156621	W10156628	Handle
20	8183253		Medallion
21	W10003360	8181747	Seal
22	W10005300	8181718	Tube, Dispenser To Bellow
23	8183180		Hose, Inlet Nozzle
24	8183182		Hose, Flowmeter
25	8181710		Hose, Inlet Valve To Vent Pipe
26	8181754	489503	Clamp

Howes
the laundry company®

Howes
the laundry company®

Howes
the laundry company®