


Whirlpool WFW97HEXW2 02 - DOOR PARTS

DOOR PARTS

For Models: WFW97HEXW2, WFW97HEXR2, WFW97HEXL2
(White) (Red) (Silver)



W10414747

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

3

Whirlpool [Residential Whirlpool WFW97HEXW2 Washer Parts](#) Parts Diagram 02 - DOOR PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10208415			Hinge Base
2	W10208398			Cap, Hinge
3	W10208419			Plate, Hinge Retainer
4	8572266			Bumper, Door
5	W10288126			Screw, 10-32 X 1/2
6	8183198	W10217552		Hook, Door
7	8540513	8182214		Screw
8	8534022			Screw, 8-18 X 1/16
9	W10208275			Frame, Door Back Support
10	W10003440	W10295703		Clamp, Glass
11	W10208263			Glass, Door
12	W10208408			Door, Outer Assembly
13	W10208269			Frame, Door Front Support
14	W10208270			Door, Outer Screen
15	W10208410			Trim Ring, Outer Door
16	W10208411			Handle, Door

