


# Whirlpool WFW97HEXW2 03 - CONTROL PANEL PARTS

## CONTROL PANEL PARTS

For Models: WFW97HEXW2 (White), WFW97HEXR2 (Red), WFW97HEXL2 (Silver)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

4

W10414747

Whirlpool [Residential Whirlpool WFW97HEXW2 Washer Parts](#) Parts Diagram 03 - CONTROL PANEL PARTS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">W10369394</a>			Console Asssembly
"	<a href="#">W10369396</a>			Console Asssembly
"	<a href="#">W10369395</a>			Console Asssembly
2	<a href="#">W10299862</a>			Handle, Dispenser Drawer
"	<a href="#">W10316367</a>			Handle, Dispenser Drawer
"	<a href="#">W10327021</a>			Handle, Dispenser Drawer
3	W10117943	<a href="#">8303811</a>		Badge, Assembly
4	<a href="#">W10406634</a>			Control Unit, Central
5	<a href="#">W10267937</a>			Harness, Jumper
6	<a href="#">W10267938</a>			Harness, UI Jumper
7	<a href="#">W10208197</a>			Bracket, Console
8	<a href="#">W10142290</a>			Screw, 8-18 X 5/16
9	<a href="#">W10317570</a>			Water Channel
10	<a href="#">W10317566</a>			Spring, Clip Water Channel
11	<a href="#">W10271988</a>			Harness, Main UI
12	<a href="#">W10271981</a>			Harness, Wiring