


Whirlpool WGD4850XQ0 01 - TOP AND CONSOLE PARTS



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

2-11 Litho in U.S.A. (LT) (psw)

1

Part No. W10394370 Rev. A

[Whirlpool Residential Whirlpool WGD4850XQ0 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10096984		Not Available	INSTALLATION (INSTRUCTIONS)
"	W10096986		Not Available	GUIDE, USE & CARE
"	W10185986		Not Available	WIRING DIAGRAM
2	W10097052			Control Panel And Bracket Assembly
3	694419			Mini-Buzzer
4	8566035	8565957		Cap, End
5	8312709			Clip-Console
6	W10103406			Panel, Rear Console
7	3405156			Switch, Rotary
8	8566032	8565954		Cap, End
9	693995			Screw, Hex Head
10	8557857			Screen, Lint
11	8536939			Clip, Knob
12	3400808			Screw, Mounting
13	688082	487210		Screw, For Mtg. Service

13	000903	407440	Capacitor
14	8533974	4331106	Screw, No.10-32 X 7/16
15	3348629	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
16	8559800	8563663	Top
17	W10117655		Switch, Push-To-Start
18	W10034380		Knob, Control
19	W10034750		Timer Knob Assembly
20	W10185981		Timer Assembly
21	W10346396		Harness, Wiring
22	3399639		Switch, Rotary Temperature

