


Whirlpool WGD4890XQ0 02 - CABINET PARTS



Whirlpool Residential Whirlpool WGD4890XQ0 Dryer Parts Parts Diagram 02 - CABINET PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8533974	4331106		Screw, No.10-32 X 7/16
2	3390631			Screw, 10-16 X 3/8
3	3390647	488729		Screw
4	3404413			Plug, Hinge Hole
5	3396795			Cover, Terminal Block
6	8564457			Plug, Front Panel
7	3396807	280040		Panel-Rear
8	342055	488627		Screw
9	3404283			Plug, Cabinet
10	3406104	3406105		Door Switch Assembly
11	697773	3395530		Screw
12	3980175			Clamp, Elbow
13	3401805			Bracket, Idler
14	3401800			Belt Shield Assembly
15	3394083			Clip, Front Panel
16	3392100	49621		Feet-Leveling

NI	279810		Foot-Optional
17	341029		Clamp, Pipe Door Spring
18	8530603	8533643	Cabinet
19	98234		Clip, U-Bend
20	690363	18776	Lock, Front Top
21	3403574	279846	Panel
22	8318272	W10465748	Burner-Gas
23	685203	279220	Clip
24	690081	279570	Latch
25	693995		Screw, Hex Head
26	W10362431		Hinge And Pin Assembly
27	696144	279570	Latch
28	3403371		Door, Inner
29	3403361		Door Front
30	8566059		Handle, Door
31	8066124	279264	Air Channel Box
32	3405245		5/16-18 X 3/4
33	344020	3401402	Cord, Power
34	8066217		Hinge, Top
35	691366		Idler And Pulley Assembly
36	W10131364	341241	Belt
37	3401802		Base, Motor
38	3400500		Bolt, 3405245 5/16-18 X 3/4
39	8066184		Pulley, Motor
40	8535934	W10396039	Motor Assembly 60 Hz
41	W10121316		Plug, Multivent
42	3404162		Clamp, Motor
43	W10236073		Bracket, Cabinet

the laundry company[®]

Howes
the laundry company[®]