


Whirlpool WGD5300SQ0 02 - CABINET PARTS



8181288

3

Whirlpool [Residential Whirlpool WGD5300SQ0 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	697776	4331106		Screw, No.10-32 X 7/16
2	343641	681414		Screw, 10AB X 1/2
3	3404162			Clamp, Motor
4	3403630			Plug, Strike Hole
"	3403632			Plug, Strike Hole
5	3396795			Cover, Terminal Block
6	693995			Screw, Hex Head
7	3396805	280043		Panel-Rear
8	8541400			Bracket, Cabinet
9	3980175			Clamp, Elbow
10	3406109	3406107		Door Switch Assembly
11	697773	3395530		Screw
14	3404413			Plug, Hinge Hole
"	3404415			Plug, Hinge Hole
16	3392100	49621		Feet-Leveling
"	279810			Foot-Optional

		Not Available	
18	N/A		Cabinet
19	98234		Clip, U-Bend
20	690363	18776	Lock, Front Top
21	3403447	279854	Panel
"	8282482	280020	Panel
23	685203	279220	Clip
24	3389441		Door Catch Assembly
25	3405246		Seal, Door Push-To-Start
27	342055	488627	Screw
28	3405514	W10362431	Hinge And Pin Assembly
29	3394083		Clip, Front Panel
33	3403431		Strike, Panel
35	3402341		Door, Inner
36	3402335		Door, Front
"	3402337		Door, Front
37	8566059		Handle, Door
"	8566071		Handle, Door
38	3406129		Seal And Bearing Assembly
45	344020	3401402	Cord, Power
49	3394975		Plug, Front Panel
"	3394978		Plug, Front Panel
51	8066217		Hinge, Top
53	691366		Idler And Pulley Assembly
56	8066065	341241	Belt
57	348780		Base, Motor
58	3400500		Bolt, 3405245 5/16-18 X 3/4
59	8066184		Pulley, Motor
62	8066206	279827	Motor-Drve
63	660658		Clamp, Motor Mounting 343481 685441
67	8318272	W10465748	Burner-Gas
68	341029		Clamp, Pipe Door Spring

