


# Whirlpool WGD5500XL1 02 - CABINET PARTS



Whirlpool [Residential Whirlpool WGD5500XL1 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	697773	<a href="#">3395530</a>		Screw
2	<a href="#">8529757</a>			Bracket, Burner
3	3390647	<a href="#">488729</a>		Screw
4	<a href="#">3394331</a>			Plate Cover
5	W10246525	<a href="#">W10314253</a>		Switch, Assembly Broken Belt
6	344020	<a href="#">3401402</a>		Cord, Power
7	<a href="#">8310656</a>			Cabinet
"	<a href="#">W10292891</a>			Cabinet
8	3392100	<a href="#">49621</a>		Feet-Leveling
NI	<a href="#">279810</a>			Foot-Optional
9	<a href="#">660658</a>			Clamp, Motor Mounting 343481 685441
10	<a href="#">3387374</a>			Spring, Idler
11	<a href="#">3389420</a>			Retainer-Idler 1/4-20 X 1/16
12	<a href="#">49252</a>			Plug, Multivent
"	W10151499	<a href="#">W10404617</a>		Plug, Multivent
13	3388672	<a href="#">279640</a>		Pulley-ldr

14	343641	<a href="#">681414</a>	Screw, 10AB X 1/2
15	8533971	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
16	342055	<a href="#">488627</a>	Screw
17	<a href="#">8563747</a>		Exhaust Pipe Medium Pipe
18	<a href="#">W10121334</a>		Washer, Thrust
19	<a href="#">W10291934</a>		Clip
20	<a href="#">690997</a>		Washer, Thrust
21	<a href="#">3387560</a>		Hinge, Door
"	<a href="#">3387559</a>		Hinge, Door
22	<a href="#">3387565</a>		Spring, Door
23	<a href="#">8066045</a>		Door Inner
"	W10304139	<a href="#">8066045</a>	Door Inner
24	<a href="#">3388229</a>		Retainer, Toe Panel
25	<a href="#">49026</a>		4" - 90° Elbow
26	697227	<a href="#">279659</a>	Panel
"	<a href="#">W10292893</a>		Upper Front Panel
27	8538263	<a href="#">279787</a>	Motor-Drve
28	<a href="#">8563750</a>		Exhaust Pipe
29	<a href="#">8578220</a>		Pulley, Motor
30	3387610	<a href="#">661570</a>	Belt
31	<a href="#">693995</a>		Screw, Hex Head
32	<a href="#">W10242878</a>		Bracket, Motor Mounting
33	<a href="#">8563749</a>		Exhaust Pipe
34	<a href="#">W10236068</a>		Bracket, Cabinet
35	<a href="#">W10284093</a>		Handle, Door
"	<a href="#">W10284094</a>		Handle, Door
36	<a href="#">693152</a>		Bumper, Console
37	<a href="#">3387242</a>		Seal, Front Panel
38	696144	<a href="#">279570</a>	Latch
39	3388674	<a href="#">W10118756</a>	Idler Bracket
40	3357011	<a href="#">308685</a>	Side Trim )
41	<a href="#">3406107</a>		Door Switch Assembly
42	<a href="#">W10325058</a>		Seal, Door
43	690081	<a href="#">279570</a>	Latch
44	<a href="#">W10279553</a>		Door, Front
"	<a href="#">W10279555</a>		Door, Front
45	697215	<a href="#">3406797</a>	Toe Panel
"	<a href="#">W10096974</a>		Toe Panel
46	<a href="#">W10312811</a>		Seal, Spill Guard
47	<a href="#">W10336128</a>		Seal, Spill Guard
NI	<a href="#">W10331132</a>		Dryer Exhaust Kit

*the laundry company*<sup>®</sup>